


# EXPLODED VIEW MODEL:SD5C



## SD5C SERVICE PARTS LIST

Updated December 30, 2008

No.	Part name	Part No.	Q'ty	No.	Part name	Part No.	Q'ty
1	Top Cover	03-041	1	24	Wire Ass'y	07-093-007	1
2	Air Filter Ass'y	08-021	1	25	Box-Control Panel	03-068	1
3	Elbow	10-023	1	26	Split Pin	12-009	4
4	PE Tube	09-017	1	27	Seat Rubber-Compressor	09-048	4
5	Nut-Flote Valve	04-011	1	28	PTC	05-021-003	1
6	Cap-Reservoir	03-063	1	29	OLP	05-020-003	1
7	Body-Float Valve	03-074	1	30	PTC Cover	05-022-001	1
8	Packing-Float Valve	09-027	1	31	Compressor	05-003B-029	1
9	Washer-Float Valve	02-034	1	32	Base-Compressor	02-020-009	1
10	Float Valve Pin	12-010	1	33	Panel	02-046	1
11	Shaft-Float Valve	02-033	1	34	Front Panel-Upper	03-003	1
12	Float	03-047	1	35	Pcb Display	07-007-005	1
13	Rectangular Baffle	03-059	1	36	Display Name Plate	03-004	1
14	Patition Tube Fitting Nut	03-067	1	37	Faucet Ass'y	23-002A-001A 23-002A-003A	2
15	Reservoir Ass'y	-	1	38	Stopper Drip Tray	03-008	1
15-1	Insulation Reservoir-Upper	08-011	1	39	Grid-Drip Tray	03-007	1
15-2	Reservoir	03-056-001	1	40	Drip Tray	03-006	1
15-3	Evaporator Copper Tube	10-022	1	41	Silicone Washer-Faucet	09-003	2
15-4	Insulation-Suction Tube	08-005	1	42	Front Panel-Lower	03-054	1
15-5	Cable Tie	17-003	1	43	Side Panel-(Right)	02-018-001	1
16	Silicon- Outlet Water Pipe	09-001	1	44	Side Panel-(Left)	02-018	1
17	Outlet Nipple Cold Reservoir	03-099	2	45	Cord Bushing	07-006-003	1
18	Patition Tube	03-065	1	46	Power Supply Cord	07-058-004	1
19	Insulation Reservoir	08-016-002	1	47	Protector-Side Panel	03-020	2
20	Base-Cold Reservoir	02-020-010	1	48	Capillary Tube	10-003-001	1
21	Door-Control Panel	03-050	1	49	Drier	05-002-001	1
22	Control Panel	02-024-011	1	50	Wire Condenser	05-008	1
23	Cold Water Thermostat	07-001	1	51	Rear Panel	03-049	1